

# QUICKSHIFTER

## EXPANSION MODULE



### PARTS LIST

- 1 Quick Shifter Module
- 1 Installation Guide
- 2 Power Commander Decals
- 2 Dynojet Decals
- 1 Velcro
- 1 Alcohol swab




### 2011-2012 Kawasaki ZX10R

#### Installation Instructions


**PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION**

**Dynojet**

2191 Mendenhall Drive North Las Vegas, NV 89081 (800) 992-4993 [www.powercommander.com](http://www.powercommander.com)



- 1 Remove the main seat and the passenger seat.
- 2 Prop the fuel tank up.
- 3 Mount the QEM on top of the battery using the supplied velcro. Make sure to clean both surfaces with the alcohol swab before attaching.
- 5 Route the QEM harness down the left side of the bike.
  
- 6 Unplug the stock wiring harness from the UPPER set of injectors (Fig. B)
  
- 7 Plug the QEM harness in-line of the stock wiring harness and UPPER injectors (Fig. C).
- 8 Plug the wiring harness from the shift sensor switch to the matching connector of the QEM.



- For the unit to function correctly the wires from the OEM must be wired correctly to the PCV. The BLUE wire goes to pin #4 and the GREEN wire goes to pin #5

- To insert the wires into the PCV strip back about 10mm of the insulation from the wire. Using a paperclip (or similar) poke the hole of the PCV to pierce the foam. It may also be helpful to tin the wire with solder for a secure connection.
- Remove the rubber seal on the back side of the PCV. Loosen the set screw of the corresponding hole and insert the wire into the PCV. Tighten the set screw. Pull on the wire to ensure it does not pull out.
- Open the PCV control center software. Go to Power Commander Tools - Configure - Features Enables and Disables - Quick Shifter. Click on the box to enable the quickshifter feature. You can adjust kill times per gear by going to Mode - Kill times per gear. For this to function you must have the speed input connected to the PCV and gear position calibrated correctly (see PCV install guide).
- Update your PCV to firmware version 1.8.8. Go to Power Commander Tools - Update firmware. The latest firmware can be found at <http://www.powercommander.com>
- This OEM can only be used with a normally open circuit shift sensor switch.