FOR USE WITH

015 Yamaha R1

Installation Instructions

### **PARTS LIST**

- **Ignition Module**
- Installation Guide
- 2 Velcro
- Alcohol swab
- CAN cable
- CAN termination plug
- USB cable





**INSTALLATION! BEFORE THIS MODULE CAN BE USED THE** POWER COMMANDER MAY NEED TO BE UPDATED.


(SEE INCLUDED INSTRUCTIONS)

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION



2191 Mendenhall Drive North Las Vegas, NV 89081 (800) 992-4993 www.powercommander.com


# IGNITION MODULE V INPUT ACCESSORY GUIDE



#### Wire connections:

To input wires into the IM first remove the rubber plug on the backside of the unit and loosen the screw for the corresponding input. Using a 22-24 gauge wire strip about 10mm from its end. Push the wire into the hole of the IM until is stops and then tighten the screw. Make sure to reinstall the rubber plug.

NOTE: If you tin the wires with solder it will make inserting them easier.



## **ACCESSORY INPUTS**

**Speed** 

This input has the ability to activate a limiter based on speed. This is intended to be used as a pit lane speed limiter. You can use any OPEN / CLOSED type switch to activate this feature.

Launch

This input is intended to be used as a launch control. You can set a target RPM to limit the bike to when the clutch lever is activated. Once the clutch lever is released full RPM can be achieved. This requires a wire be connected to the grounding side of the clutch switch and the other end into this input.

Ground


This is a digital ground. You can connect the BLACK/WHITE crank wire of the SFM to this location if necessary.

Analog-


Not currently used - updates to follow

Crank-

Connect the WHITE crank wire from the SFM (if installed) to this input. This is only needed if you are going to use the Rev Xtend feature.







- 1 Remove the main seat.
- Remove the fuel tank and airbox. 2
- Place the ignition module next to the PCV and route the harness towards the 3 front of the bike going down the right side of the bike.

Make sure the harness does not interfere with the throttle linkage

Unplug the stock wiring harness from each coil stick (Fig. A)

5 Plug the Ignition Module in-line of the stock wiring harness and each coil stick (Fig. B).

Attach the ground wire of the Ignition Module to the common ground location on the top of the engine case (Fig. C).

This is the same ground location as the PCV.






Route the Ignition Module harness underneath the fuel tank bracket (Fig. D).

You will need to remove the 2 bolts on the right side and loosen the 2 bolts on the left side of the bracket to get the harness underneath it.

- Plug the CAN cable into 1 of the ports of the Ignition Module and the other end into 1 of the ports of the PCV.
- Plug the CAN termination plug (plastic) into any one of the remaining open ports of the Ignition Module or PCV.
- Install the Ignition Module next to the PCV. Connect the WHITE and BLACK/WHITE wires of the Ignition Module to the PCV module wire inputs, as described on Page 5. Use the supplied velcro to secure the unit in place. Make sure to clean both surfaces before attaching with the alcohol swab.

Due to limited room on this motorcycle the installation is shown where the stock exhaust servo motor would normally be. When this is removed it allows ample room. You can use Dynojet part # ESRM-1 to eliminate the servo motor. If you are keeping the servo motor in place then there is room on the right side of the battery to install either the PCV or Ignition Module.

11 Reinstall the airbox and fuel tank.



#### **Connecting the Ignition Module to the PCV:**

- The WHITE and the BLK/WHT wires from the Ignition Module MUST be connected to the PCV module.
- Connect the WHITE wire from the Ignition Module to the #1 input position of the PCV. Connect the BLK/WHT wire to the #4 input position of the PCV. The BLK/WHT wire can also be connected to the #6 input position of the PCV if necessary.
- If you are also using the SFM (Secondary Fuel Module) then you will need to connect the WHITE and BLK/WHT wires from the SFM into the Ignition Module. Connect the WHITE wire from the SFM to the #1 input position of the Ignition Module. Connect the BLK/WHT wire to the #4 input position of the Ignition Module. The BLK/WHT wire can also be connected to the #6 input position of the Ignition Module if necessary.

#### Adding the Ignition Module to the PCV network:

- First download the latest version of Control Center software which is 1.0.6.4.
- To use the Ignition Module you may need to update your firmware in the PCV (and SFM if being used). Make sure the units are updated to firmware version 0.1.10.6 or newer. Go to VIEW Device Information to see the current version. If you need to update the firmware go to Power Commander Tools Update firmware. The latest version of firmware and software can be found on the downloads page of www.powercommander.com or on the included CD.
- Connect a USB cable to the PCV and another USB cable to the Ignition Module. The software will ask you to add the Ignition Module to the network. Click OK. Go to Power Commander Tools Manage Network and click on Sync Devices Utility. Follow the on screen instructions.