

POWER COMMANDER 6

Installation Guide for: PC6-16003

Model Coverage: 2009-2012 Honda CRF450R

PARTS LIST



- | | |
|----------------------|--------------------------|
| 1 POWER COMMANDER 6 | 2 POWER COMMANDER DECALS |
| 1 INSTALLATION GUIDE | 1 ZIP TIE |
| 1 USB CABLE | |
| 2 DYNOJET DECALS | |


**PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION.
THE IGNITION MUST BE TURNED OFF BEFORE INSTALLATION.**



IPC6-16003.01



INPUT ACCESSORY GUIDE




OPTIONAL ACCESSORY INPUTS

- Map** (Input 1 or 2) The PC6 has the ability to hold 2 different base maps. You can switch on the fly between these two base maps when you hook up a switch to the MAP inputs. You can use any open/close type switch. The polarity of the wires is not important.
- Shifter** (Input 1 or 2) Used for clutch-less full throttle upshifts. Insert the wires from the Dynojet quick shifter into either Input 1 or Input 2. The polarity of the wires is not important. Set to Input 2 by default.
- Speed** If your application has a speed sensor then you can tap into the signal side of the sensor and run a wire into this input. This will allow you to calculate gear position in the Control Center Software. Once gear position is setup you can alter your map based on gear position and setup gear dependent kill times when using a quick shifter.
- Analog** This input is for a 0-5v signal such as engine temp, boost, etc. Once this input is established you can alter your fuel curve based on this input in the Power Core software.
- Launch** You can connect a wire to either Input 1 or Input 2 and then the other end to a switch. This switch when engaged (continuity) will only allow the RPM to be raised to a certain limit (set in the software). When released, you will have full RPM.

WIRE CONNECTIONS

To input wires into the PC6 first remove the rubber plug on the backside of the unit and loosen the screw for the corresponding input. Using a 22-24 gauge wire, strip about 10mm from its end. Push the wire into the hole of the PC6 until it stops and then tighten the screw. Make sure to reinstall the rubber plug.

NOTE: If you tin the wires with solder it will make inserting them easier.



INSTALLING THE POWER COMMANDER 6



- 1 Remove the seat and fuel tank.
- 2 Using the supplied zip tie, secure the PC6 to the stock ECU.

Make sure the PC6 wiring harness sits in the recess of the rubber guard on the frame.



- 3 Unplug the stock wiring harness from the injector.




- 4 Connect the PC6 in-line of the stock wiring harness and the injector.


- 5 Unplug the Throttle Position Sensor (TPS) harness.

This connector is located on the left side of the throttle body to the inside of the frame. It can be difficult to access and unplug.

This is a BLUE 3-pin connector.



- 6 Plug the PC6 harness in-line of the stock TPS and wiring harness.




- 7 Attach the ground wire of the PC6 to the stock ground location.

This is the mounting tab for the right side radiator.

- 8 Reinstall the fuel tank and seat. Make sure the tank does not pinch the PC6 wiring harness.

Download the latest map files from our web site at dynojet.com/tunes.





**PUSH
THE
LIMIT**

2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM
© 2009-2022 DYNOJET RESEARCH ALL RIGHTS RESERVED