



Mounting Suggestions

**Harley-Davidson® FX/FL Big Twin 1965-1984
Solo Seat**

Mounting Suggestions

**Harley-Davidson® FX/FL Big Twin 1965-1984
Passenger Seat**

Mounting Suggestions

**Harley-Davidson® FX/FL Big Twin 1965-1984
Two-Piece Seat**



Mounting Suggestions

Harley-Davidson® FX/FL Big Twin 1965-1984

Solo Seat

Tools Required:

- Phillips Screwdriver
- SAE Wrenches or Sockets

Hardware:

- Stock Rear Fender Screw
- Two rubber expansion plugs with threaded inserts and bolts (Included for Solo Only installation)

Baseplate Features:

The 16 gauge formed steel baseplate is black powder coated. Rubber bumpers on the solo and carpet on the rear seat prevent them from touching the frame or fender.

Stock One-Piece Seat Removal Steps

1. Remove rear fender screw located behind the passenger seat.
2. Slide seat back and up.

Mounting of Mustang Solo Seat

1. Insert threaded rubber expansion plugs into hollow frame cross tube located halfway between tank and fender. (Fig. I)
2. Slide solo front forks under frame and align side brackets so they go over rubber expansion plugs.
3. Use supplied bolt and thread through bracket into expansion plug.
4. Tighten bolts until expansion plugs are snug to complete the installation process. (Fig. II)

Fig. I



Fig. II



Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an email to questions@mustangseats.com, or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".



Mounting Suggestions

Harley-Davidson® FX/FL Big Twin 1965-1984

Passenger Seat

Tools Required:

- Phillips Screwdriver

Hardware:

- Stock Rear Fender Screw



Baseplate Features:

Mustang passenger seats have two chrome tabs that align with mounting holes in the back of the solo. Chrome rear tab matches stock fender hole. The baseplate features elastic polyurethane rubber bumpers to protect the motorcycle and soften vibrations as well as carpet to protect the fender.

Stock One-Piece Seat Removal Steps

1. Remove rear fender screw located behind the passenger seat and set aside. The stock rear fender screw will be used to attach your new Mustang Passenger Seat.
2. Slide seat back and up.

Mounting of Mustang Passenger Seat

1. Remove two screws from back of Mustang solo seat.
2. Align two chrome tabs located at the front of the passenger seat with holes in back of solo.
3. Screw rear seat and solo together.
4. Align chrome rear tab located at back of passenger seat with hole in fender.
5. Secure with stock fender screw to complete the installation process.

Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern, or send an email to questions@mustangseats.com, or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75563, 75561, 75556, 75340, 75557, 75763, 79113, 79133

[back](#)



Mounting Suggestions

Harley-Davidson® FX/FL Big Twin 1965-1984

Two-Piece Seat

Tools Required:

- Phillips Screwdriver

Hardware:

- Stock Rear Fender Screw
- Two rubber expansion plugs with threaded inserts and bolts (Included for Solo Only installation)

Baseplate Features:

The 16 gauge formed steel baseplate is black powder coated. Rubber bumpers on the solo and carpet on the rear seat prevent them from touching the frame or fender.



Stock One-Piece Seat Removal Steps

1. Remove rear fender screw located behind the passenger seat and set aside. The stock rear fender screw will be used to attach your new Mustang Two-Piece Seat.
2. Slide seat back and up.

Mounting of Mustang Solo & Passenger Seat

1. Remove two screws from back of Mustang solo seat.
2. Align two chrome tabs located at the front of the passenger seat with the mounting holes in back of solo.
3. Screw rear seat and solo together.
4. Slide solo front forks under frame.
5. Align chrome rear tab located at back of passenger seat with stock hole in fender.
6. Secure in place with stock fender screw to complete the installation process. *Note: Use of side brackets optional and would use the rubber expansion plugs, threaded inserts, and bolts used for a solo only installation.*

Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75527, 75557, 79103, 79113, 75756, 75763, 79123, 79133, 75562, 75563, 75056, 75338, 75561, 75556, 75340