

INSTALLATION

SADDLEBAG LID COVERS

4118

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - •The product must be properly installed, maintained and operated under normal conditions.
 - •Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- •Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year.

 This includes, but is not limited to; control modules, wiring, chrome & other components.
- •Küryakyn makes no warranty of any kind in regard to other manufacturer¹s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339,

Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.

PARTS INCLUDED

- Saddlebag Lid Cover, Right
 Saddlebag Lid Cover, Left
- 16 4" x 1" Adhesive-Backed Hook and Loop
- 2 Alcohol Pads
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

NOTICE

IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.

TOOLS SUGGESTED

Set of Torx Wrenches, Scissors, Clean Soft Rag, Warm Soapy Water.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2

Clean both saddlebag lids inside and out with warm soapy water and a clean rag; rinse and allow to fully dry.

NOTICE

Ensure the area of installation is free of grease, oil, dirt or other debris including wax/polish products and bugs to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.





Küryakyn

- STEP 3 Start with the right side, remove the two Torx screws that secure the retaining strap and set them aside, they will be reused. PIC 1
- STEP 4

 Use the alcohol pad from the hardware kit to clean the area inside of the saddlebag as shown in PIC 2 where the hook and loop strips will be installed. Let dry completely.
- STEP 5 Cut one of the 1"x 4" strips in half to make two 1"x 2" strips, to use for the cover's small tabs.
- STEP 6 Place the correct cover on the lid (Küryakyn Logo will be in the back) and fold the tabs over the lid to determine mounting location for the hook and loop adhesive strips.
- **STEP 7** Mark the location of the tabs with a non-permanent marker or masking tape, then remove the cover. PIC 3



The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

- STEP 8 Using the back of your fingernail, rub the adhesive backing on the hook and loop strips to activate the catalyst.
- Remove the adhesive backing, press and hold the strip in place for one (1) minute in the locations marked by the tape. Full bonding strength will occur in 24 hours.
 - NOTE: For best results, do not fasten the cover tabs to the hook and loop strips. Allow the adhesive to cure for 24 hours before attaching lid cover.
- **STEP 10** Repeat the process for all of the adhesive hook and loop strips using the strips that were cut in half for the small tabs. PIC 3
- **STEP 11** Re-install the retaining strap with the screws that were removed in STEP 3.
- **STEP 12** Repeat STEP 3 through STEP 11 for the left side.

NOTICE AI

Allow the adhesive to cure for 24 hours before installing the cover, or failure of adhesive may occur.

Ride On!

PAGE





