



## Mounting Suggestions: 2013-2014 Yamaha Bolt Fender Bibs

**Hardware included:** 2 8mm x 15mm chrome button head bolts  
(for studded bib only - plain bib will use  
stock bolts)

**Tools needed:** 4mm Allen wrench

### Mounting of Mustang fender bib:

1. Remove the seat from the motorcycle.
2. Remove the two rear most Allen bolts from the fender with a 4mm Allen wrench.
3. Attach the rear of the fender bib to the fender with either the stock bolts (plain bib) or supplied chrome bolts (studded bib). Do not over tighten. (fig. 1)
4. Stretch the elastic on the front of the bib around the fender bracket which mounts the back of the solo. (fig. 2)
5. Re-install the solo seat.



### **Enjoy the comfort and custom look of your new Mustang seat!**

These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to [questions@mustangseats.com](mailto:questions@mustangseats.com) or visit our website at [www.mustangseats.com](http://www.mustangseats.com).

For care and maintenance of our seats,  
please go to our website under "Support".

Refers to part numbers:  
78149, 78150

