## **Instructions for Linbar® Part** # **504-1**

504-1 fits Indian Chief Classic/ Vintage 2014-Present



- 1. Remove bolt that secures the brake line to the lower Triple Tree.
- 2. Install the Linbar between the Frame and the Brake Line.
- 3. Install the two 8mm bolts on the top mounts.
- 4. Install the Left and Right lower 10mm Bolts
- 5. Tighten all bolts to manufacturer's specifications including bolt removed from the brake line.

\*Hardware Included:

- -2 x bolts 8mm x 25mm
- -2 x bolts 10mm x 25mm

