

INSTALLATION INSTRUCTIONS

ATTENTION INSTALLER (if other than owner): Please forward this Instruction Sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing this Air Cleaner Brace and Breather Kit on 91-06 XL models with CV carburetors.

Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A **NOTE:** provides key information to make procedures easier or clearer.

CAUTION: (Shaded) A **CAUTION:** indicates special procedures that must be followed to avoid damage to the motorcycle and/ or accessories.

WARNING: (Boxed and shaded) A **WARNING:** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

3/4" combination wrench
9/16" combination wrench
5/32" hex key wrench
9/16" socket wrench

DRAG SPECIALTIES AIR CLEANER SUPPORT/ BREATHER KIT P/N DS-289126

PROCEDURE:

1. Remove the stock air cleaner and filter, including the backing plate.
2. Slip one of the washers over the banjo bolt, then fit the banjo fitting onto the banjo bolt. Place another washer over the bolt.
3. Place the carb support bracket over the carb and align with the mounts on the heads. Place the banjo bolts from step #2 into the carb support bracket.
4. Position the banjo fittings in the direction desired before tightening. When tightening the banjo bolts make sure the carb mounting holes are aligned with the holes in the support bracket.
5. Using 3/8" I.D. rubber hose, install on the barbed fittings on banjos and route to the included Tee fitting. From the Tee fitting route a single hose to the fitting on the backside of the air cleaner. Make sure there are no restrictions or kinks in these hoses.

NOTE: As an alternative to routing the breather into the air cleaner, you may place the small breather in place of the tee from step 6. Allow the filter to hang below the carburetor, making sure it does not interfere with any movement of the carburetor linkage. Make sure the vent hole on the back of the air cleaner is plugged to prevent unfiltered air from entering the engine.

6. Install the air cleaner of your choice. The mounting bracket should be in between the carb and the air cleaner.

WARNING: Make sure all hardware is tight before operating motorcycle.