

INSTALLATION

ENGINE GUARDS WITH FIXED FOOTREST 4582

FOR VTX1300

FITS: ALL '03-UP VTX1300 MODELS

Note: Not intended for use with Küryakyn Cruise Peg Mounts (P/N 4519)

PARTS INCLUDED

- 1 Engine Guard Assembly, Right
- 1 Engine Guard Assembly, Left
- 1 Hardware Kit, including:
 - 2 M10 x 1.25 x 70mm Hex Flange Head, Chrome
 - 4 M10 x 1.25 x 60mm Hex Flange Head, Chrome
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE

CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR

SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein

may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of hex wrenches, combination wrenches or socket set with a ratchet.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

RIGHT SIDE PROCEDURE

STEP 1 Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EHXHAUST SYSTEM

DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM

HAVE FULLY COOLED TO PREVENT INJURY.

ATTENTION! Check clearance for proper operation of controls. Engine guards provide

additional positions to place your feet/new-riding positions. Confirm clearance

and relation of the position of your feet to the shifter and brake pedals.

STEP 2 Remove the fasteners securing the footrests to the frame; they will not be used again. (See <u>PIC. 1</u> for location)

-cont.-

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

 Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

· The product must be properly installed, maintained and operated under normal conditions.

• Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

 Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.

> · Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.

Küryakyn electrical products are warranted for one
(1) year from the date of purchase by the consumer.
Components of Küryakyn products containing L.E.D.s.
will be warranted for defects in materials and
workmanship for 3 years from the date of purchase.

· Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today–select the "CATALOGS" icon. Each Küryakyn" product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



STEP 3 Using the M10 x 1.25 x 70mm bolt (the additional 60mm bolt may be be used on the right side of the mounting bracket, it is the same thickness as the left side bracket), install engine guard on the outside of the forward controls mounting bracket. (See <u>PIC. 2</u>)

LEFT SIDE PROCEDURE

STEP 1 Remove the bolts securing the footrests to the frame; they will not be used again.

STEP 2 Using the M10 x 1.25 x 60mm bolts install the engine guard on the outside of forward controls mounting bracket, shown in $\underline{PIC. 3}$.

ATTENTION! It is the installer's responsibility to ensure that all of fasteners (including preassembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance

may be required.

WARNING! ENSURE THAT THERE IS PROPER CLEARANCE FOR YOUR FEET TO OPERATE THE FORWARD CONTROLS (BRAKE AND SHIFTER).

DAUNCE. THE ADDITION OF ENGINE CHARDS MAY AFFECT CODMEDING

WARNING! THE ADDITION OF ENGINE GUARDS MAY AFFECT CORNERING CLEARANCE IN SOME SITUATIONS.

WARNING! IMPROPER INSTALLATION OR USE OF THIS PRODUCT MAY RESULT IN

SERIOUS INJURY OR DEATH.

Ride On!



Küryakyn

PIC. 1