



IN60-245L

Ignition Cover

Installation Instructions

- 1) Remove the OEM cover from the motor and unbolt the stator assembly.
- 2) Attach the skid plate to the Woodcraft cover by bolting it from the inside. Each bolt should have an o-ring (supplied) on it before assembly.

IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS

- 3) Attach the stator and wire retainer using the OEM hardware to the Woodcraft cover. Be sure that the retainer does not contact the rotor before assembly.
2007+ MUST use Woodcraft provided hardware.

IMPORTANT - USE THREADLOCKING COMPOUND ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

- 4) Completely clean the engine gasket surface.
- 5) Install the Woodcraft cover with a new gasket using the OEM mounting hardware.



IN60-245L

Ignition Cover

Installation Instructions

- 1) Remove the OEM cover from the motor and unbolt the stator assembly.
- 2) Attach the skid plate to the Woodcraft cover by bolting it from the inside. Each bolt should have an o-ring (supplied) on it before assembly.

IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS

- 3) Attach the stator and wire retainer using the OEM hardware to the Woodcraft cover. Be sure that the retainer does not contact the rotor before assembly.
2007+ MUST use Woodcraft provided hardware.

IMPORTANT - USE THREADLOCKING COMPOUND ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

- 4) Completely clean the engine gasket surface.
- 5) Install the Woodcraft cover with a new gasket using the OEM mounting hardware.



IN60-245L

Ignition Cover

Installation Instructions

- 1) Remove the OEM cover from the motor and unbolt the stator assembly.
- 2) Attach the skid plate to the Woodcraft cover by bolting it from the inside. Each bolt should have an o-ring (supplied) on it before assembly.

IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS

- 3) Attach the stator and wire retainer using the OEM hardware to the Woodcraft cover. Be sure that the retainer does not contact the rotor before assembly.
2007+ MUST use Woodcraft provided hardware.

IMPORTANT - USE THREADLOCKING COMPOUND ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

- 4) Completely clean the engine gasket surface.
- 5) Install the Woodcraft cover with a new gasket using the OEM mounting hardware.



IN60-245L

Ignition Cover

Installation Instructions

- 1) Remove the OEM cover from the motor and unbolt the stator assembly.
- 2) Attach the skid plate to the Woodcraft cover by bolting it from the inside. Each bolt should have an o-ring (supplied) on it before assembly.

IMPORTANT - USE THREADLOCKING COMPOUND ON THE THREE SKID PLATE MOUNTING BOLTS

- 3) Attach the stator and wire retainer using the OEM hardware to the Woodcraft cover. Be sure that the retainer does not contact the rotor before assembly.
2007+ MUST use Woodcraft provided hardware.

IMPORTANT - USE THREADLOCKING COMPOUND ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

- 4) Completely clean the engine gasket surface.
- 5) Install the Woodcraft cover with a new gasket using the OEM mounting hardware.