

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES GRIP CAPS WITH 12" FRINGE FOR 82-96 HARLEY-DAVIDSON® MODELS WITH OEM RUBBER GRIPS DS-243064

ATTENTION INSTALLER: (if other than owner):
Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing the Drag Specialties Fringed Grip Caps onto 82-96 Harley Davidson® models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION!: (shaded) A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING!: (boxed and shaded) A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

Soapy water

PROCEDURE:

1. Start with the left hand grip. Apply a soapy water solution to the very end of the rubber grip (around the raised portion). Push the Fringed Cap onto the bottom corner of the grip, at an angle. Grip the cap in the palm of your hand, and firmly pull up and push toward the grip. The rubber should deform slightly and should be slippery enough to slip over the end of the grip. The inside of the cap has a lip and this fits over the lip on the end of the grip.

2. Repeat Step 1 on the right grip. This side may require slightly more force to pull the Cap up and over the end of the grip, as the grip is thinner on this side.

CAUTION!: Before operating the motorcycle, make sure that all hardware is tight and the throttle operates freely and does not stick.



DRAG SPECIALTIES

Box 9336, Minneapolis, MN 55440

PRINTED IN TAIWAN, R.O.C.

Page 1 of 1