

Custom Dynamics® Dynamic Lower Fairing Solid Blocker Plates Installation Instructions

We thank you for purchasing the Custom Dynamics® Dynamic Lower Fairing Solid Blocker Plates. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-LF-BLOCK

Package Contents:

- Lower Fairing Solid Blocker Plates (Pair)
- Isopropyl Alcohol wipe (1)

Use with Custom Dynamics® Lower Fairing Lights (PN: CD-LF-AW-B 2020-1919), sold separately





ATTENTION



Please read all Information below before Installation

<u>Warning</u>: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

<u>Safety First</u>: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: Ambient install temperature must be 60 degrees F or higher.

Allow 24 hours for tape to cure before washing or prolonged use of vehicle.

Installation:

- 1. If installed, remove both of the Lower Fairing Lights from the Lower Fairings.
- 2. Using the provided Isopropyl Alcohol wipe, clean around the grill area on the rear side of both Lower Fairing Lights.
- 3. Remove the red protective tape from the Lower Fairing Solid Blocker Plates.
- 4. Attach the Lower Fairing Solid Blocker Plates to the back side of both Lower Fairing lights. The radius corners should be towards the top of the light. Note that the Lower Fairing Solid Blocker Plates are labeled Left and Right.
- 5. Install or re-install both Lower Fairing Lights. Refer to the CD-LF-AW-B installation instructions.
- 6. Test all lighting for proper operation.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST