



Custom Dynamics® Micro Turn Signal Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Micro Turn Signal Adapter. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: MPR-MICROAW-18ST

Package Contents:

- Micro Turn Signal Adapter (2)



Fits: 2018-2023 Harley-Davidson® Softail® Models

Installation:

1. Disconnect the negative battery cable from the battery.
2. Refer to the factory service manual and remove the gas tank from the bike.
3. Locate and remove the terminal rubber boot cover from the front left side of the frame exposing the terminal block, refer to Photo 1.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2.

4. Disconnect the left and right front turn signal lighting harnesses from the terminal block connector. Refer to Photo 2.
5. Connect one of the Micro Turn Signal Adapter harnesses in-line with the bike's front RIGHT turn signal lighting harness and the terminal block connector. Connect one of the Micro Turn Signal Adapter harnesses in-line with the bike's front LEFT turn signal lighting harness and the terminal block connector.
6. Carefully tuck the Micro Turn Signal Harnesses into the backbone cavity and re-mount the terminal block along with the terminal block rubber boot. Be sure to leave the Female connectors of the Micro Turn Signal Harnesses outside of the rubber boot as shown in Photo 3.
7. Connect the Micro Turn Signals (Sold Separately) to the installed Micro Turn Signal Adapters.
8. Secure wires to prevent the wires from becoming cut, frayed, or pinched.
9. Reconnect the negative battery cable to the battery and reinstall the seat.
10. Test operation of all lighting before riding.

