



Custom Dynamics®

ProBEAM® Amber/White 1156

Turn Signals Installation Instructions

We thank you for purchasing the Custom Dynamics® ProBEAM® Amber/White 1156 LED turn signals! Our LEDs offer maintenance free service and higher visibility. Our ProBEAM® product line utilizes the latest technology and automotive grade components to ensure the highest level of reliable service. Custom Dynamics® offers one of the best warranty programs and customer support in the industry. If you have any questions during the installation of this product please call us at 1(800) 382-1388.

Part Number: PB-AW-1156, PB-AW-ECE-1156

US Patent 830597, 830595

Chinese Patent ZL201830045649.4, Other Patent Pending

Package Contents:

- ProBEAM® LED Clusters (1 pair)
- Smoked ProBEAM® Lenses (1 pair)

Fitment: Front turn signals on Harley-Davidson® US Models with 1156 single contact bases and Bullet Style (Pop-off) lens. Does not fit 2016 - 2022 CVO™ Models



ATTENTION

Please read all Information below before Installation

Note:

- Use care in removing the OEM lens and bulbs from the housing, so as not to scratch or mar the chrome housing. Custom Dynamics® is not liable for damage to chrome housing during installation.
- Dielectric grease does not need to be used with this LED product, it can actually prevent them from working. Remove any excess grease from your turn signal sockets before inserting.
- NOTE: When inserting the base use the proper sized 5/16" Flathead screwdriver. Using too small of a screwdriver will damage the base and void the warranty.

*****IMPORTANT*****

CAN Bus Models: This LED product is BCM compliant. However, you must run the 4 way hazard flashers for 3 minutes to allow the BCM to sync the new load after the new LED turn signals are installed.

Non CAN Bus Models: A SMART Signal Stabilizer® or Load Equalizer is required to ensure proper turn signal function and have the proper flash speed.



Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

Installation:

1. Remove the existing lens from turn signal housing.
2. Remove existing bulb from turn signal housing.
3. Remove any corrosion or dielectric grease from the socket to insure the socket contacts are clean.
4. Using a small flat blade screwdriver, go around the perimeter of the reflector and slightly push the black gasket into the housing to allow proper clearance of the new LED turn signal (Refer to Figure 1).
5. Route white wire through turn signal housing, this may require drilling a 1/8" hole in the back of the reflector and/or housing.
6. Connect white wire to a running light power source.
7. Insert the socket base into the socket.
8. Twist the LED turn signal a few rotations to coil wire from the turn signal to the socket base. Insert LED turn signal into housing and install new lens.
9. Check operation of turn signal in all modes.

Caution

1. If there is a gap between the lens and the housing, water will leak into the unit and cause damage, be sure the lens is fully seated all the way around the perimeter.
2. If the lens will not fully seated on the housing, it may be necessary to trim any excess gasket with a small flat blade screw driver. Refer to Figure 2 .
3. Do not use the lens if any of the tabs are broken, doing so may cause water to enter the housing.
4. Do not install the lens without the ProBEAM lens gasket in place, doing so will cause water to leak into the housing.
5. For additional troubleshooting, please scan the QR code in Figure 3.

