KRAUS WORKMAN KICKBACK RISERS X ++ INSTALL GUIDE

KRAUS WORKMAN KICKBACK RISERS:

UN-RI-10 UN-RI-15 UN-RI-17 UN-RI-19

- -Riser can be installed onto tree and torqued according to spec
- Kraus workman risers will retain OEM bushings in top tree
- -Bars can be installed directly into riser, once clocking of bars is determined, (6) 5/16-18 bolts can be installed and torqued to spec

OPEN ROAD KITS:

NOTE: Bushings will be supplied in Open Road Kits OEM rubber bushings can be removed from top tree and discarded. Replacement hard bushings will have to take their place

- -Riser can be installed onto tree and torqued according to spec
- -Bars can be installed directly into riser, once clocking of bars is determined, (6) 5/16-18 bolts can be installed and torqued to spec





