



## Custom Dynamics® Low Rider S Headlight Mounting Bracket Installation Instructions

We thank you for purchasing the Custom Dynamics® Low Rider S Headlight Mounting Bracket. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800)382-1388.

**Part Numbers:** MOUNT-V2-FXLRS

### **Package Contents:**

- Headlight Mounting Block (1)
- Instructions (1)

**Fitment:** 2020-2025 Harley-Davidson® Low Rider S (FXLRS).

Compatible with Custom Dynamics® 5.75" Softail Headlight Bucket: CD-18ST-BUCKET (**sold separately**).



### **Installation:**

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Remove the OEM Headlight assembly, headlight mount and unplug headlight connector. Save the two OEM mounting bolts for reuse.
3. Mount the new Custom Dynamics® Low Rider S Headlight Mounting Bracket using the two OEM mounting bolts.
4. Install the new Custom Dynamics® Headlight Bucket and LED Headlight (**sold separately**) to the Custom Dynamics® Low Rider S Headlight Mounting Bracket. Refer to the Headlight Bucket and Headlight instructions for installation.
5. Reconnect the negative battery cable to the battery and reinstall all necessary parts.
6. Test the new Custom Dynamics® or ProBEAM® LED Headlight for proper operation.



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on the motorcycle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure the motorcycle is on level surface, secure and cool.

Questions? Email: [info@CustomDynamics.com](mailto:info@CustomDynamics.com) or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST