



### **Installation Instructions**

**BMW S1000RR 2020**

**Water Pump Cover Protector**

**60-0757WPC**

- 1) Drain the coolant from the motorcycle.  
(This can be avoided if you are extremely careful not to disturb the OEM cover)
- 2) Install the Woodcraft water pump cover protector over your OEM cover using the included (3) 04-SC630Z mounting bolts.  
Torque for these mounting bolts is about 7 ft-lbs.
- 3) Refill the coolant and tighten the drain bolt (if needed)
- 4) Start the motorcycle and inspect for any leaks before riding.



### **WARNING**

Installation of Woodcraft Billet Covers involves removal and reinstallation of certain factory components such as fasteners, alternator stators and oil-retention gaskets. FAILURE TO INSTALL THESE COMPONENTS IN COMPLIANCE WITH ALL SPECIFIC INSTRUCTIONS SUPPLIED WITH BILLET COVER KIT, MAY CAUSE OIL LOSS OR DAMAGE TO ENGINE RESULTING IN LOSS OF CONTROL OF MOTORCYCLE AND SERIOUS INJURY OR DEATH.