Custom Dynamics® Magic Strobes™ BCM Installation Instructions

We thank you for purchasing the Custom Dynamics® Magic Strobes brake Flasher! Our products utilize the latest technology and high quality components to ensure you the brightest, most reliable LED's on the market. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Package Contents:

- Magic Strobes™ Brake Flasher (1)
- Tie Wraps (5)

This Magic Strobes™ Brake light Flasher is plug and play for the following 2014 and up Models: Road King Standard & CVO, Electra Glide Ultra Classic, Electra Glide Ultra Limited, Limited CVO.

Installation

- 1. Locate Rear Wiring Harness Under Seat (See reference photos)
- 2. Unplug male and female connectors.
- 3. Plug in Magic Brake Strobe
- 4. Secure using enclosed tie wraps
- 5. Select Desired Pattern with Power Off
- 6. Check Operation
- 7. To change Mode, turn bike off and change dial to desired pattern.





Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Custom Dynamics® Magic Strobes™ BCM Installation Instructions

We thank you for purchasing the Custom Dynamics® Magic Strobes brake Flasher! Our products utilize the latest technology and high quality components to ensure you the brightest, most reliable LED's on the market. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Package Contents:

- Magic Strobes™ Brake Flasher (1)
- Tie Wraps (5)

This Magic Strobes™ Brake light Flasher is plug and play for the following 2014 and up Models: Road King Standard & CVO, Electra Glide Ultra Classic, Electra Glide Ultra Limited, Limited CVO.

Installation

- 1. Locate Rear Wiring Harness Under Seat (See reference photos)
- 2. Unplug male and female connectors.
- 3. Plug in Magic Brake Strobe
- 4. Secure using enclosed tie wraps
- Select Desired Pattern with Power Off
- Check Operation
- 7. To change Mode, turn bike off and change dial to desired pattern.





Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

07-2014SM 07-2014SM

Custom Dynamics® Magic Strobes™ BCM Installation Instructions





Flash Pattern Information

For Use with Incandescent or LEDs:

- Pattern 0: Four Flashes then Solid
- Pattern 1: Four Flashes, Solid for 3 Seconds, Repeat
- Pattern 2: Seven Flashes then Solid
- Pattern 3: Seven Flashers, Solid for 3 Seconds, Repeat

For use with LEDs Only:

- Pattern 4: Quad Strobe then Solid for 1 Second then Quad Strobe
- <u>Pattern 5</u>: Quad Strobe, Solid for 1 Second, then Quad Strobe, Solid for 3 Seconds, then Repeat
- Pattern 6: Blaster X Pattern for 3 seconds, then Solid
- Pattern 7: Constant Blaster X Pattern
- Pattern 8: Constant Fast Strobe 5 Seconds, then Solid
- Pattern 9: Constant Fast Strobe Pattern





Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Custom Dynamics® Magic Strobes™ BCM Installation Instructions





Flash Pattern Information

For Use with Incandescent or LEDs:

- Pattern 0: Four Flashes then Solid
- Pattern 1: Four Flashes, Solid for 3 Seconds, Repeat
- Pattern 2: Seven Flashes then Solid
- Pattern 3: Seven Flashers, Solid for 3 Seconds, Repeat

For use with LEDs Only:

- Pattern 4: Quad Strobe then Solid for 1 Second then Quad Strobe
- <u>Pattern 5</u>: Quad Strobe, Solid for 1 Second, then Quad Strobe, Solid for 3 Seconds, then Repeat
- Pattern 6: Blaster X Pattern for 3 seconds, then Solid
- Pattern 7: Constant Blaster X Pattern
- Pattern 8: Constant Fast Strobe 5 Seconds, then Solid
- Pattern 9: Constant Fast Strobe Pattern





Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

07-2014SM 07-2014SM