



FLARE® CARE

Failure to maintain your polycarbonate windshield can result in damage and will void your warranty.



STOP

Do not clean polycarbonate in hot sun or high temperatures. Sunlight reflections off the inside curvature of the windshield can, at certain times of the day, cause extreme heat build-up on motorcycle instruments. Exercise care in parking. Park facing the sun, place an opaque object over the instruments, or adjust the windshield to avoid reflections.



CAUTION!

Do not use petroleum based or ammonia based cleaners including rain-sheeting products on Klock Werks windshields. Do not use benzene, paint thinner, gasoline or any other type of harsh cleaner on the windshield. Powdered abrasive or alkaline cleanser will damage the windshield. Anything labeled as a glass cleaner or found in an aerosol container is not recommended to be used on our polycarbonate windshields. Use of these products could cause dulling, hazing, peeling of the hardcoat and in some cases fractures in the material.

Never scrape the windshield with a razor blade or other sharp instrument.

Klock Werks will not be held responsible for any damages incurred as a result of misuse or improper care.



FLARE® CARE

To obtain a proper high-end polish, please use a quality protector and polish. Klock Werks recommends Shine Werks, our cleaner formulated specifically for care of your Flare® Windshield, with a clean microfiber towel. Mild soapy water is also acceptable.



QUESTIONS

When in doubt, ask it out! Contact us at info@getklocked.com or (605) 996-3700 with any questions you may have.

GETKLOCKED.COM