



CHICANE™ MIRRORS

- WARNING** This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.
- CAUTION** This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.
- ATTENTION** This indication alerts you to the fact that if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Included Items:



Installation Instructions:

1. Park on a level surface and shut off motorcycle. Ensure the engine has time to cool before installation. Protect surfaces to prevent accidental damage.
2. Remove OEM acorn nut and remove mirror. Fig. 1
3. Insert provided screw and lock washer through hole from bottom and tighten into mirror arm. Fig. 2 Repeat steps 2 and 3 on other side of motorcycle.

NOTE: Use a 3/32" hex wrench to loosen or tighten tension of mirror adjustment at screw shown in Fig. 3.

NOTE: Chicane Mirrors come pre-assembled but it is the installer's responsibility to check fasteners for tightness. Please use the following recommendations for confirming tightness. Use a medium thread lock fluid (blue color typically) on the 1/4-20 .750 socket head cap screw shown to the right, circled in green in Fig. 3. Torque to 120IN.LB. (13.5nm).

