

# Installing Rox Riser Kit for Indian Scout (Part #4R-P2RIN)

Note: This riser kit will only work with the stock handlebar/clamp assembly.

## Parts List:

- (4) SILVER 8mm x 30mm Bolts
- (4) BLACK 8mm x 35mm Bolts
- (2) Rox Riser Bodies
- (2) Rox Riser Caps

**STEP #1:** Place towel on gas tank. Remove OEM handlebar by loosening the (4) stock bolts.

**STEP #2:** Place the risers into the OEM handlebar clamps and use the caps provided with risers to fasten risers to triple clamp. Lightly secure the riser into position by using the (4) SILVER 30mm bolts provided with the risers. You will NOT be reusing the stock Indian bolts.

**STEP #3:** Place the OEM handlebar in position on top of the Rox riser bodies, being careful to set the left/right distance of the risers in order to line up with the holes in the Speedo bracket. Place the Indian OEM Speedo bracket on top of Rox Riser bodies and and tighten down using the (4) BLACK 35mm bolts provided in the Rox riser Kit.

**STEP #4:** Adjust the risers and handlebar to your preferred position, tighten all bolts down to 18-20 foot lbs.



SILVER  
30mm bolts

ROX Caps

BLACK 35mm bolts



Completed  
Install

**WARNING!** Improper installation of Rox Speed FX, Inc Risers can seriously affect the safety of your motorcycle! If you are unsure of your ability to properly install this product, please have the product installed by a qualified motorcycle technician. Rox Speed FX, Inc Inc takes no responsibility for damage or physical harm caused by improper installation or use of these risers at speeds in violation of posted speed limits. It is solely the customers responsibility to verify there is no interference between moving parts, cable interference, cable binding, or excessive cable tension. Cables must not be under tension or rub against other parts when handlebars are fully turned in either direction. Rox Speed FX, Inc Inc cannot be held liable in the event of an accident involving operator error or malfunction of installed part. All screws, bolts and nuts, including all replacement hardware provided by Rox Speed FX, Inc Inc should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. All screws, bolts and nuts should be checked after driving the first 40 miles to ensure that they have maintained their proper torque. **IMPORTANT:** Rox risers are NOT designed to be used with clip-on style handlebars!