



MOUNTING SUGGESTIONS:

Harley-Davidson® Chopped Tour-Pak® Pad 2014-2015

Hardware:	1/4"-20 nuts x 3
	1/4" zinc washer x 3
	Rubber bumpers x 3
Tools needed:	7/16" nut driver or wrench

Installation of Mustang Backrest:

Note: Mustang backrest installs
ONLY on Chopped Tour-Pak®
2014 and up.

1. Open Tour-Pak®, locate and remove the three hex nuts holding stock pad in place and remove.
2. Note locations of mounting holes in the lid.
3. Remove all supplied hardware from the studs on the back of the Mustang backrest except the rubber bumpers.
4. Align the studs with the holes in the Tour-Pak®, and push through.
5. Place one zinc washer and one hex nut on the studs inside of the lid. Tighten all three securely.



Enjoy the comfort and custom look of your new Mustang seat!

These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 76870, 76871, 76872

You are cordially invited to
— Tour the Mustang Factory —

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.