EE Installation Instructions

- Remove the air box cover (fig. 1).
- 2 Using a 10mm socket remove the 8mm bolt for the OEM chain guide (fig. 2).
- 3 Using an 8mm socket remove the three 6mm bolts for the slave cylinder and OEM chain guide (fig. 3).
- Connect the supplied 8mm clip nut to the knockdown bar as shown (fig. 4).
 - 4a NOTE: Be sure the threads of the clip nut are on the same side as the "016" part #.
- Using the supplied M8x55mm hex head bolt, fasten the provided spacer, chain slider and knockdown bar as shown (do not tighten at this time) (fig. 5).
 - 5a NOTE: be sure the opposite side of the knockdown bar is positioned as shown (fig. 6).

- 6 Using the provided M6x40mm hex head bolts, mount the clutch guard over the slave cylinder and wire (fig. 7).
 - 6a Make sure the wire is positioned within the clearance area inside the clutch guard.
 - 6D Push the slave cylinder guard and slave cylinder up against the engine cases with your hand.
 - 6c Align the 3 bolts in the slave cylinder guard and tighten the three bolts in a star pattern to ensure a square fit.
- Refer back to step 5 and tighten the 8mm bolt at this time.
 - 7a NOTE: Make sure the chain slider is rotated up against the air box (fig. 5).
- 8 Have fun and ride safe!















WARNING AND DISCLAIMER

All parts manufactured, designed or sold by Entire Engineering, Inc. (EEI) are to be installed by a Econosel motorcycle designed in Econosel motorcycle designed may be included in the Econosel motorcycle designed in the sold in the Econosel motorcycle designed in a disposely design and and properly design access real real marked parts. (EE) scuttures must exercise good pingeneer lat the sea, created, alteration, part schedels can ad installance of their motorcycles. In the residence of a possible desiction and scale and a manufactured, designed or sold by EE, the responsibility of EEI is institute faultiers are stilled or the parts being of the part in EEI destinants being and the part is EEI destinants being and the part is EEI destinants being and the part is EEI destinants and the EEI products will void this limited warrantyl. EEI, under on circumstances will be responsible for incidental and corrections and access properly disappears. personal injury disappear, or damage, injury, or or despised or sold by EEI, the scale of the circumstances will be responsible for incidental and corrections and any claim part is an experiment injury disappears or damage, injury, or or despised or part when the correct and part is an experiment injury disappears or damage, injury, or or despised or part injury despised or sold by EEI, the scale of the Correct and the scale or the followers of the correct and the



QUALITY OFF-ROAD MOTORCYCLE PRODUCTS

INSTRUCTIONS

Installation Instructions

Part# 13-2021