



MX LIFT STAND

PART: 320012



You need



x2 (A)



x3 (B)




x9 (C)




x1 (D)



x2 (E)




x1 (F)



(1) B - C - A - F - ARM - C - A - C - E

(2) B - C - ARM - C - D

(3) B - C - A - C - BRACKET - C - A - C - E



Pull the arm to the down position and use pliers to attach the hook side of the spring to the pre-drilled hole.

