

WOODCRAFT

60-0500LB Alternator Cover Installation Instructions

1) Remove the OEM cover from the motor and unbolt the stator assembly

2) Attach the stainless steel skid plate to the Woodcraft cover by bolting it from the inside. Each bolt should have an o-ring (supplied) on it before assembly.

IMPORTANT - USE RED PERMANENT LOCTITE ON THE THREE SKID PLATE MOUNTING BOLTS

3) Attach the stator to the Woodcraft cover. There are three spacer washers included in the kit. These washers must be placed under the head of the OEM bolts before bolting the stator to the Woodcraft cover.

IMPORTANT - USE RED PERMANENT LOCTITE ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

4) Attach the wire retainer clip using the OEM hardware to the Woodcraft cover. Be sure that the retainer does not contact the rotor before assembly.

IMPORTANT - USE RED PERMANENT LOCTITE ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

5) Completely clean the engine gasket surface

6) Install the Woodcraft cover with a new gasket using the OEM mounting hardware

WOODCRAFT

60-0500LB Alternator Cover Installation Instructions

1) Remove the OEM cover from the motor and unbolt the stator assembly

2) Attach the stainless steel skid plate to the Woodcraft cover by bolting it from the inside. Each bolt should have an o-ring (supplied) on it before assembly.

IMPORTANT - USE RED PERMANENT LOCTITE ON THE THREE SKID PLATE MOUNTING BOLTS

3) Attach the stator to the Woodcraft cover. There are three spacer washers included in the kit. These washers must be placed under the head of the OEM bolts before bolting the stator to the Woodcraft cover.

IMPORTANT - USE RED PERMANENT LOCTITE ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

4) Attach the wire retainer clip using the OEM hardware to the Woodcraft cover. Be sure that the retainer does not contact the rotor before assembly.

IMPORTANT - USE RED PERMANENT LOCTITE ON ALL OF THE STATOR / RETAINER MOUNTING BOLTS

5) Completely clean the engine gasket surface

6) Install the Woodcraft cover with a new gasket using the OEM mounting hardware