FACTORY ACTIVATED SEALED BATTERY INSTRUCTIONS


Read and follow the instructions before installing this battery

Valve Regulated, AGM Lead Acid Battery (Factory Activated Sealed)

This battery is factory activated and has been filled with electrolyte and fully charged at the factory.

Prior to installation and before placing the battery into service, the state of charge (open circuit voltage) must be checked with a voltmeter.

A refreshing charge may be required depending on the state of charge. Refer to table on page 2 to determine if recharging is required.



CHARGING METHODS

- If using an automatic type charger, refer to the charger instructions to ensure proper recharging.
- If using a constant current type charger, refer to the charge current (A) shown on the battery or charging rate chart.

State of Charge	Open Circuit Voltage	Status	Charge Time Required (Constant Current)
100%	12.8 or Higher	No Recharge Required	None. Recheck Voltage in 3 Months
75% - 100%	12.5 - 12.8	May require Recharge	3 - 5 hours
50% - 75%	12.0 - 12.5	Recharge	5 - 8 hours
25% - 50%	11.5 - 12.0	Recharge	8 - 10 hours
0% - 25%	11.5 or Less	Recharge	10 hours

Note: Wait for at least 1 hour after battery is removed from charger to check voltage.

CAUTIONS - GENERAL INSTRUCTIONS

- Do not attempt to fast charge or permanent battery damage could result.
- Only use chargers specified for powersports batteries.
- Charge battery before use and during extended periods of inactivity.

 The way that the vehicle charging protein in free installing installing in the line.
- Ensure that the vehicle charging system is functional before installing battery.
- Only Install the correct battery for the application as originally specified by the vehicle manufacturer and position the battery as originally supplied in the vehicle.
- Do not attempt to open or modify the battery in any manner.

INSTRUCTIONS FOR PERIODIC MAINTENANCE

- Always maintain the battery in a charged condition. Do not subject to deep discharge.
- Keep battery clean and free of dirt and grime. Inspect battery for signs of abnormal wear.
- Keep terminals clean and ensure cables are tightly fastened and free of wear or damage.

CONSTANT VOLTAGE CHARGING RATE CHART

Battery Type Number	Volt (V)	Capacity Ah (10HR)	Max. Charge Current
ALL CT2,5L	12	2.5	0.75
ALL CT4B	12	2.5	0.75
ALL CT(X)4L	12	3	0.9
ALL CTŽŚS	12	3.5	1.05
ALL CT(X)5L	12	4	1.2
ALL CTôB	12	6	1.8
ALL CTX7	12	6	1.8
ALL CTZ7S	12	6	1.8
ALL CT7B	12	6.5	1.95
ALL CTX9	12	8	2.4
ALL CT9B	12	8	2,4
ALL CTZ10S	12	8.6	2.58
ALL CTX12	12	10	3
ALL CT12A	12	10	3
ALL CTZ12S	12	11	3.3
ALL CT12B	12	11	3.3
ALL CTZ14S	12	11.2	3.36
ALL CTX14	12	12	3.6
ALL CT14B	12	13	3.9
ALL CTX15	12	13	3.9
ALL CTX14H	12	14	4.2
ALL CTH16	12	14	4.2
ALL CTX16	12	14	4.2
ALL CTX20	12	18	5.4
ALL CTX16CL-B	12	19	5.7
ALL CTX19	12	19	5.7
ALL CTX18	12	21	6.3
ALL CTX24	12	21	6.3
ALL CTX30L	12	28	8.4
U1-32 (UTV-Yamaha Rhino)	12	32	9.6
51913 (FA)	12	19(20HR)	5.7

A DANGER/POISON



SHIELD EYES. **EXPLOSIVE GASES** CAN CAUSE BLINDNESS **I ●FLAMES**



NΛ SPARKS



SULFURIC ACID **CAN CAUSE** I BLINDNESS OR I . SMOKING I SEVERE BURNS.

FLUSH EYES IMMEDIATELY WITH WATER.





OR INJURY.

KEEP OUT OF THE REACH OF CHILDREN.



READ INSTRUCTIONS.

DO NOT OPEN BATTERY, DO NOT COVER VENT OPENINGS. CALIFORNIA PROPOSITION 65 WARNING: Batteries, battery posts,

terminals and related accessories contain lead and lead compounds, and other chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. WASH HANDS AFTER HANDLING.



BATTERY MUST BE RECYCLED



NON-SPILLABLE **AGM BATTERY**

Q2034-1 Rev. 4 07/14 Y