

Letric Lighting Co.

MOTORCYCLE LIGHTING

www.namzccp.com

NAMZ Custom Cycle Products, Inc

1440 Ulmer Avenue
Oreland, PA 19075

Technical Support is available Monday-Friday, 9am-5pm EST via email at tech@namzccp.com or call us at 1-877-277-NAMZ.

Part Number: LLC-5LRA-TS



Fitment: LED Road Glide Headlamp with integrated SWITCHBACKS™ turn signals for 2015-Up Road Glide models. A mixture of black & chrome accents, housing is built with plastic, aluminum and a poly-carbonate lens, DOT, SAE and E-Mark compliant and 100% plug-n-play.

This product is intended: The SHARKTOOTH™ Headlamp with integrated SWITCHBACKS™ turn signals not only enhances the appearance of a 2015-Up Road Glide but will also increase rider visibility and safety as the SHARKTOOTH™ offers 3911-lumes on low beam and 7999 on high beam. Running Lights provide a bright white light when riding and amber turn signals. Dressed in a mixture of black & chrome accents, the SHARKTOOTH™ housing is built with heavy duty mounting brackets, aluminum body, with a poly-carbonate lens, DOT compliant, and 100% plug and play.

What is included in this kit?

- (1) Sharktooth™ Headlamp
- (1) Plug-n-Play Turns Signal Harness
- (2) Mounting Blocks
- (4) 10-32 bolt and nut
- (4) #10 Star Washer

Recommended Tools:

- T25 Torx Bit
- T15 Torx Bit
- 1/8" Allen Head Socket
- 3/16" Allen Head Socket

WARNING!

This product should be installed by a professional motorcycle technician or reputable shop/ dealership.

Improper installation may result in loss of Headlamp / Turn signal functions.

1. Remove seat and disconnect the negative battery cable.
2. Remove the four windscreen bolts using 1/8" Allen Head, and set aside.
3. Carefully, remove speaker pod lids and upper fairing bolts, located under speaker pod lids. and lower fairing bolt using T25 Torx.
4. Using the 3/16" Allen Head remove turn signal mounting bolts. Use appropriate precautions here as the outer fairing is not no longer attached to the motorcycle. Disconnect the turn signal connectors, and carefully set the fairing aside in an area it will not be damaged.
5. Remove stock headlamp using 3/16" Allen Head. Two of the bolts are located on the top of the light and two below.
6. Disconnect headlamp connector by gently prying the locking tab up and pulling the connectors apart.
7. Remove the Fairing vent covers from the stock head lamp using the T15 Torx.
8. Install fairing vents on the Sharktooth™ headlamp using the supplied button head Allen screws. Use the star washers to ensure the bolts will not come loose.
9. Using blue Loctite attach the top mounting brackets with the supplied Allen head screws.
10. Install the Plug-n-Play turn signal harness and route the wires in a way they will not be pinched by the outer fairing.
11. Connect the headlamp connector and turn signal harness to the Sharktooth™ headlamp. Reinstall headlamp with the stock bolts. Refer to service manual for torque specifications.
12. Reinstall outer fairing in reverse order, referring to service manual for torque specifications.
13. Reconnect battery and test functions.

(continued)

Letric Lighting Co.

MOTORCYCLE LIGHTING

www.namzccp.com

NAMZ Custom Cycle Products, Inc

1440 Ulmer Avenue
Oreland, PA 19075

Technical Support is available Monday-Friday, 9am-5pm EST via email at tech@namzccp.com or call us at 1-877-277-NAMZ.

Below you will find a color schematic of the proper installation for our LED headlamp.

